

# NORMAN HYDE



## Triumph 12" Disc Brake Kit

### CONTENTS

1. 12" DISC X 1
2. ALUMINIUM MOUNTING PLATE X 1
3. CALIPER MOUNTING BOLTS X 2
4. PLAIN WASHERS X 2
5. SPRING WASHERS X 2
6. ALLOY CALIPER X 1 (OPTIONAL)



### FITTING

1. REMOVE FRONT WHEEL
2. REMOVE BRAKE CALIPER
3. PLACE A PLAIN WASHER ON EACH OF THE ORIGINAL CALIPER MOUNTING STUDS. PUSH ON THE NEW CALIPER MOUNTING PLATE AND SECURE USING THE ORIGINAL WASHERS AND NUTS. (IF YOUR FORK LEG HAS CALIPER BOLTS RATHER THAN STUDS YOU MUST STILL MAKE SURE A PLAIN WASHER IS FITTED BETWEEN FORK LEG AND NEW MOUNTING PLATE.)
4. FIT CALIPER USING NEW BOLTS AND SPRING WASHERS SUPPLIED.
5. FIT NEW DISC TO WHEEL USING ORIGINAL NUTS AND CLEAN DISC WORKING FACES.
6. FIT WHEEL BACK IN FORKS AND CHECK THAT CALIPER IS CENTRAL ON THE DISC AND THERE IS AT LEAST 3mm CLEARANCE BETWEEN OUTSIDE DIAMETER OF THE DISC AND THE CALIPER TO ALLOW FOR DISC HEAT EXPANSION.
7. CONNECT BRAKE LINE AND BLEED SYSTEM.
8. RE-CHECK ALL NUTS AND BOLTS. FIT ORIGINAL CHROME COVER IF REQUIRED.
9. TAKE CARE WITH FIRST USE AS SOME RUNNING IN OF PADS TO NEW DISC IS REQUIRED.