



IF FITTED WITH ORIGINAL BTH CONDENSER

BEFORE




AFTER




BEFORE

IF FITTED WITH POTTED NON-ORIGINAL CONDENSER



AFTER



The C05 EasyCap is fitted between the two brass castings of the contact breaker assembly in place of the insulating plate(s) which should be removed.